All manuals and user guides at all-guides.com

Microsoft Zune

Audible User Guide



System Requirements:

○ Windows Operating System(s):	Windows XP SP2 + Vista	○ AudibleManager Version:	5.5 or above
○ Mac Operating System(s):	N/A	○ Windows Media Player Version:	N/A
○ Firmware Version:	3.0 or above	○ Zune Software Program:	2.5 or above

* Please note, for information on updating your Zune to support Audible, please visit:
FAQ 3800 - Using Microsoft Zune with Audible

Audible Features:

○ Audible Formats Supported:	4	○ Section Navigation:	Yes
○ Bookmarking:	N/A	○ Variable Playback Speed:	N/A

All manuals and user guides at all-guides.com

Device Layout:

All manuals and user guides at all-guides.com

How To's:

Playback - *How do I locate and play Audible content on my device?*

Step 1. From the main window scroll to and select **audiobooks**.
Step 2. Scroll to and select the title you want to play.
Step 3. Select play to begin playing the selected title.

Rewind/Fast-Forward - *How do I rewind or fast-forward an Audible book?*

Rewind

Step 1. Press and hold the pad to the left.

Fast-Forward

Step 1. Press and hold the pad to the right.

Section Navigation - *How do I navigate through sections within an Audible book?*

Step 1. During playback press the pad to the left once to return to the previous section.
Step 2. During playback press the pad to the right once to skip to the next section.